

## DECLARATION OF CONFORMITY



EC – Declaration of Conformity according to;

Machinery Directive 2006/42/EC

Restriction of Hazardous Substances Directive 2011 / 65 / EU

Electromagnetic Compatibility Directive 2014/30/EU

We, **Toolsave Limited**, located at **Unit C, Manders Ind. Est., Old Heath Road, Wolverhampton, WV1 2RP, United Kingdom**, declare in exclusive responsibility that the **compressor AIR50L** meets the essential health and safety requirements of the above-mentioned directives.

To ensure presumption of conformity, the product has been assessed for compliance with the following directives and standards either in part or in full.

Directive	Requirements and / or Standards applied
Machinery Directive 2006/42/EC	EN 61029-1:2009+A11:2010 EN 61029-2-1A:2012+A11:2013
RoHS 2 Directive 2011 /65 / EU	Directive 2011/65/EU
Electromagnetic Compatibility Directive 2014/30/EU	EN 55014-1:2006/A2:2011 EN 55014-2:1997/A2:2008 EN 61000-3-2:2014 EN 61000-3-11:2000

TCF reference no. : AIR50L

Name: Bill Evans

Title: Company Director

Signature:

04/11/2019



**50 Litre Oil Free Compressor**  
**Belt Driven**  
**AIR50L**



## ORIGINAL INSTRUCTIONS



**AIR50L**

# TABLE OF CONTENTS

## Welcome to Lumberjack!

Dear customer, Congratulations on your purchase. Before using the Product for the first time please be sure to read these instructions for use. They provide you with all information necessary for using the product safely and to ensure its long service life.

Closely observe all safety information in these instructions!

<b>General Power Tool Safety Warnings.....</b>	<b>01</b>
<b>Symbols &amp; Cable Rating Chart .....</b>	<b>05</b>
<b>Machine Details and Product features.....</b>	<b>06</b>
<b>Operation.....</b>	<b>07</b>
<b>Parts Diagram.....</b>	<b>10</b>
<b>Parts list.....</b>	<b>11</b>
<b>Lumberjack Guarantee.....</b>	<b>12</b>
<b>Declaration of conformity.....</b>	<b>14</b>

# LUMBERJACK GUARANTEE

## 2. Claims Procedure

2.1 In the first instance please contact the Authorised Dealer who supplied the product to you. In our experience many initial problems with machines that are thought to be faulty are actually solved by correct setting up or adjustment of the machine. A good Authorised Dealer should be able to resolve the majority of these issues much more quickly than processing a claim under the guarantee. If a return is requested by the Authorised Dealer or Lumberjack, you will be provided with a Returns Material Authorisation Number which must be clearly stated on the returned package, and any accompanying correspondence. Failure to provide a Returns Material Authorisation Number may result in the item being refused at the warehouse.

2.2 Any issues with the product resulting in a potential claim under the guarantee must be reported to the Authorised Dealer from which it was purchased within 48 hours of receipt.

2.3 If the authorised Dealer who supplied the product to you has been unable to satisfy your query, any claims made under this guarantee should be made directly to Lumberjack. The claim itself should be made in writing setting out the date and place of purchase, giving a brief explanation of the problem which has led to the claim.

2.4 Please note that it is essential that the claim reaches Lumberjack on the last day of the guarantee at the latest. Late claims will not be considered.

## 3. Limitation of Liability.

3.1 We only supply products for domestic and private use. You agree not to use the product for any commercial, business or resale purposes and we have no liability to you for any loss of profit, loss of business, business interruption or loss of business opportunity.

3.2 This guarantee does not confer any rights other than these expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an extra benefit and does not affect your statutory rights as a consumer.

## 4. Notice

This guarantee applies to all product purchased from an Authorised Dealer of Lumberjack within the United Kingdom. The terms of the guarantee may vary in other countries.



AIR50L



AIR50L

## LUMBERJACK GUARANTEE

### Guarantee

1.1 Lumberjack guarantees that for a period of 12 months from the date of purchase the components of qualifying products (see clauses 1.2.1 to 1.2.8) will be free from defects caused by faulty construction or manufacture

1.2 During this period, Lumberjack, will repair or replace free of charge any parts which are proved to be faulty in accordance with paragraph 1.1 providing that:

1.2.1 You follow the claims procedure set out in clause 2.

1.2.2 Lumberjack and its Authorised Dealers are given reasonable opportunity after receiving notice of the claim to examine the product.

1.2.3 If asked to do so by Lumberjack or its Authorised Dealer, you return the product at your own cost to Lumberjack's or the supplying Authorised Dealer's Premises -

For the examination to take place clearly stating the Returns Material Authorisation Number given.

1.2.4 The fault in question is not caused by industrial use, accidental damage, fair wear and tear, wilful damage, neglect, incorrect electrical connection, misuse, alteration or repair of the product without approval.

1.2.5 The product has been used in a domestic environment only.

1.2.6 The fault does not relate to consumable items such as blades, bearings, drive belts or other wearing parts which can reasonably be expected to wear at different rates depending on usage.

1.2.7 The product has not been used for hire purposes.

1.2.8 The product has been purchased by you, as the guarantee is not transferable from a private sale.

## GENERAL POWER TOOL SAFETY WARNINGS

**WARNING Read all safety warnings and all instructions.** Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

**Save all warnings and instructions for future reference.** The term "power tool" in the warnings refers to your electric (corded) power tool or battery-operated (cordless) power tool.

### 1. Work Area safety

a) **Keep your work area clean and well lit.** Cluttered or dark areas invite accidents.

b) **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.

c) **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

### 2. Electrical safety

a) **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with grounded power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.

b) **Avoid body contact with grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is grounded.

c) **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.

d) **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep the cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.

e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.

f) **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

### 3. Personal safety

a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.

b) **Use personal protective equipment. Always wear eye protection.** Protective equipment such as a dust mask, non-skid safety boots, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

c) **Prevent unintentional starting. Ensure the switch is in the off position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

d) **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.

## GENERAL POWER TOOL SAFETY WARNINGS

e) Do not overreach. Keep a stable footing at all times. This enables better control of the power tool in unexpected situations.

f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.

### 4. Power tool use and care

a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.

b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

c) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.

d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.

e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.

f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier

g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

### 5. Service

a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

b) If the replacement of the supply cord is necessary, this has to be done by the manufacturer or its agent in order to avoid a safety hazard.

### 6. Battery Tool Use and Care

a) Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.

b) Use power tools only with specifically designated battery packs. Use of any other battery packs may create a risk of injury or fire.

NO	Designation	Qty	NO	Designation	Qty
1	Plastic Housings	1	36	Mats Bolt	2
2	Rock Switch	1	37	Flat Gasket	4
3	Elbow	1	38	Foot Pad	2
4	Cylinder Head	1	39	Nut	2
5	Silencer	1	40	Bolt	4
6	Cylinder Head Gasket	1	41	Pressure Regulating Valve	1
7	Valve Block	2	42	Bolt	4
8	Valve Plate	2	43	Watch 40	1
9	Aluminium Spacer	1	44	Quick Answer	1
10	Head Gasket	1	45	Plastic Housings	1
11	Bolt	2	46	Pipe	1
12	The Plastic Handle	1	47	Check Valve	1
13	Nut	2	48	Plug Cord	1
14	Gland	1	49	Capacitor	1
15	Packing Cup	1	50	Bearing 6203	1
16	Connecting Rod	1	51	Flat Gasket	1
17	Air Cylinder	1	52	Jump Ring	1
18	High Voltage Tube	1	53	Crank Case	1
19	Fan Blade	1	54	Starter	1
20	Bearing 6001	2	55	Rotor	1
21	Crank Throw	1	56	Carbon Fibre	1
22	Belt	1	57	Bolt	2
23	Belt Wheel	1	58	Bearing	1
24	Pressure Relay	1	59	Plastic Housings	1
25	Hand Shank	1	60	Fan Blade	1
26	Plastic Mattress	1	61	Jump Ring	1
27	The Throat Mouth Elbow	1	62	Bearing 608	1
28	Socket Head Cap Screw	4	63	Bolt M5	1
29	Axle	2	64	Bolt N6*20	3
30	Flat Gasket	4	65	Spring Washer	3
31	Wheel	2	66	Flat Gasket	3
32	Spring Washer	2	67	Bolt N5*16	1
33	Nut M8	2	68	Flat Gasket	1
34	Gasholder	1	69	Bolt M4	1
35	Drain Plug	1			